

POCKET
**SMART
STRING**
PATENTED
Pull the string. Read the screen!
User Manual



Stores up to 3 measurements (inches or metric).
No need to write them down.

How to use Pocket SmartString
How to measure something using the Pocket SmartString

- 1) Turn it on by using either the **ON/C** or **CALC MEAS** button (press & hold for 2 seconds).
- 2) Press the **CALC MEAS** button to toggle from "CALC" mode to "MEAS" mode.
- 3) Pull the string! Read the screen for the distance measured.
- 4) To save the distance, use one of the "Capture Button."
- 5) Go to "CALC" mode to retrieve the saved distance.



TROUBLESHOOT:

- **SMARTSTRING WILL NOT TURN ON:** Push the button for the light. If it comes on, then the unit may need to be reset. To reset the SmartString, press the reset button located on top of the device. If the light does not turn on, then you may need new batteries. (2 x CR-2032)
- **STRING DOES NOT RETRACT:** Push top left button forward to make sure it didn't lock in place
- **IT IS NOT ACCURATE:** Try to measure it again. PSS is designed to measure by 1/8 (.125) inches. Sometimes PSS will be off by 1/8 of an inch. By measuring again, you can compare your second measurement with your first to be sure it is accurate.
- **SMARTSTRING WILL NOT TURN OFF:** PSS will automatically turn off after 2 minutes of not being used.
- **STRING BROKE:** This is covered under the warranty. See below for instructions on how to send it back.
- **BUTTON QUIT WORKING:** This is covered under the warranty. See below for instructions on how to send it back

1-Year Limited Warranty

Pocket SmartString (PSS) warrants all products against defects in materials and workmanship for a period of one (1) year from the date of original consumer purchase in the U.S. If a defect exists during the warranty period, PSS at its option will either repair (using new or remanufactured parts) or replace (with a new or remanufactured unit) the product at no charge.

THE WARRANTY WILL NOT APPLY TO THE PRODUCT IF IT HAS BEEN DAMAGED by MISUSE, ALTERATION, ACCIDENT, IMPROPER HANDLING OR OPERATION, OR IF UNAUTHORIZED REPAIRS ARE ATTEMPTED OR MADE. SOME EXAMPLES OF DAMAGES NOT COVERED by WARRANTY INCLUDE, BUT ARE NOT LIMITED TO, BATTERY LEAKAGE, BENDING, OR VISIBLE CRACKING OF THE LCD, WHICH ARE PRESUMED TO BE DAMAGES RESULTING FROM MISUSE OR ABUSE.

Disclaimer

PSS MAKES NO WARRANTY OR REPRESENTATION, EITHER EXPRESS OR IMPLIED, WITH RESPECT TO THE PRODUCT'S QUALITY, PERFORMANCE, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. AS A RESULT, THIS PRODUCT, INCLUDING BUT NOT LIMITED TO, KEYSTROKE PROCEDURES, MATHEMATICAL ACCURACY AND PREPROGRAMMED MATERIAL, IS SOLD "AS IS," AND YOU THE PURCHASER ASSUME THE ENTIRE RISK AS TO ITS QUALITY AND PERFORMANCE.

PSS IS NOT A TOY. DO NOT MISUSE THE STRING. PSS CONTAINS SMALL PARTS. KEEP OUT OF REACH OF CHILDREN. IN NO EVENT WILL PSS BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY DEFECT IN THE PRODUCT OR ITS DOCUMENTATION.

The warranty, disclaimer, and remedies set forth above are exclusive and replace all others, oral or written, expressed or implied. No PSS dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

Some states do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you.



Product Returns

Customers wishing to return Pocket SmartString to Pocket Workmate, Inc. must send it along with a check or M/O for the amount of \$6.95 for return S&H charges and your name, address and phone #. A new or your repaired PSS will be returned in 6-8 weeks.

Pocket Workmate, LLC
3775 EP True Pkwy Suite 252
West Des Moines, IA 50265
www.PocketSmartString.com




Capture Distance Buttons – These 3 buttons will capture the distance of measurement, while in "MEAS" mode. You don't need to write it down. Just pull the string to measure and push one of these buttons to store it. To retrieve the distance of measurement, you must be in "CALC" mode. You can use your measurements with the calculator.

 CALC MEAS BLUE BUTTON	Use this button to toggle between "CALC" or "MEAS" mode. This button also turns on the calculator after you push it for 2 seconds. CALC mode is the default.	 in mm YELLOW BUTTON	Use this button to toggle between inches (in) or metric millimeters (mm). You can use this in "CALC" mode also. Default is "in" mode.
--	--	--	---

Slide Button on top left back to lock the string in place. The button on the right, when pushed, turns the LED light on.



To turn on the calculator, push this button for 2 seconds. The "C" will clear even in MEAS mode. While in CALC mode you cannot clear a measurement. The only way to clear a measurement out of 1/H, 2/W or 3/D is to take another measurement on top of the old one.



To measure a distance longer than 40 inches

Pull out the string to 40 inches, then press **1/H** and then from there, bring the SmartString to that point and do it again but this time, press **2/W**.

Using "CALC" mode, add the two distances together and you have your total measurement.

